Step-by-step instructions

For sprayers that draw from a 5-gallon bucket

1 INSTALL THE INSERT

Press the insert evenly to the bottom of the bucket for a snug fit, with the center cup facing up. Place the uptake hose in the center cup.

2 MEASURE YOUR SYSTEM

Find out how much fluid your pump, all hoses and gun(s) hold. Measure with water and record the total system fluid capacity before painting.

3 ADD YOUR PAINT

Pour in the amount of paint you need for your project.

4 SPRAY YOUR PROJECT

Spray normally, drawing down the paint in the bucket. Keep the uptake hose positioned in the center cup.

5 ADD WATER AND PUSH

When the bucket is empty and you will not add more paint, add water equal to your measured system fluid capacity. Use the remaining paint normally until water reaches the gun, then begin cleaning.

After use: Clean the bucket and insert before paint dries. The insert can remain in the bucket for reuse. Not for solvent-based paints.